

## **Eye Tubes not found in the Stark 9-66 & Marconi MU-101 Manual**

**(Please Note: Bias and English adjustment can be left in any position)**

### **OCTAL (K8A) SOCKETS BELOW;**

#### **6X6 EYE TUBE**

6.3 V.A.C. J R 5 4 3 6 0 EYE CLOSED

6.3 V.A.C. J R 5 4 0 6 0 EYE OPEN

#### **10E/305 (CV1103) EYE TUBE**

6.3 V.A.C. J R 5 4 3 7 0 EYE CLOSED

6.3 V.A.C. J R 5 4 0 7 0 EYE OPEN

### **LOKTAL (B8B) SOCKET BELOW;**

#### **EM71**

6.3 V.A.C. J R 6 2 5 7 3 EYE CLOSED

6.3 V.A.C. J R 6 2 0 7 3 EYE OPEN

### **MINIATURE 7 PIN (B7G) BELOW;**

#### **6M-E5 (6ME5)**

6.3 V.A.C. J R 7 5 2 1 0 EYE CLOSED

6.3 V.A.C. J R 7 5 0 1 0 EYE OPEN